



3.080 Stoves Introduction

While there are a variety of options available, most camps will use either propane stoves or Coleman stoves.



Propane stoves can be used with either disposable propane cartridges, or refillable propane tanks. They offer the advantage of ease of use, since once assembled, it is only necessary to turn the control knob on, and light the stove.

Which ever type of stove is used, employ common sense rules just as you would around a stove in the home:

- ◆ Place the stove at the end of the picnic table where the dining fly canvas is highest, making sure that there is nothing near that could catch fire.
- ◆ Make sure that hair is tied back and that sleeves are tight and not dangling. Beware of nylon clothing.