



## 3.082 Coleman Stoves - Operation

### TO PUMP UP THE FUEL TANK

1. Rotate the pump knob 3 times to the left.
2. Place thumb over the small hole in the knob, pull out the plunger and pump it vigorously, about 20 times until it resists.
3. Keeping the finger over the hole, push plunger in and rotate pump knob to the right until tight.

### TO LIGHT THE STOVE

1. Turn air valve to "up" position.
2. Strike match and hold flame over master burner, keeping your hand well to the right.
3. Turn on the gas with control knob. Remove match as soon as gas lights. Turn on gas fully, and immediately, turn it down until a "good" flame is burning.
4. Flames should turn to a steady blue flame within a minute.
5. Turn down air valve 1 minute after lighting. Put on grate.

### AUXILIARY BURNER

1. To light auxiliary burner, hold a lighted match over burner, pull out valve and turn it away from you.
2. To turn it off, turn valve towards you and push in.

If the flame goes down while cooking, you can pump up the gas without turning off the gas.

### TO TURN STOVE OFF

Make sure that the auxiliary burner is turned off.

1. Turn up air valve during last minute of burning.
2. Turn off main control knob.
3. When flame is out, release pressure in fuel tank to avoid leaking. Unscrew filler cap slowly. When pressure is released screw cap tightly.
4. Clean stove after each use to avoid flare-ups, clogging of gas line, and easier final clean-up.