



3.085 Coleman Stoves - Problems

IF YOUR STOVE WILL NOT LIGHT:

1. Check tank to see if there is enough gas.
2. Re-pump fuel tank.
3. Check to see if the generator nozzle is fitting securely into the mixing chamber, (usually cause of gas leakage).
4. Check the ring on the nozzle to make sure it is tight. Use wrench to tighten.
5. Sometimes carbon gets in the mixing chamber. This can sometimes be cleared by removing the fuel tank, giving the mixing chamber a few taps with a wrench, turning the stove upside down and shaking the carbon out.

